



CODE	NAME	
1	2.02HLT1509030701	Cover of switch
2	1.05.085011DKJ1XXCS	Timer HLP-15DKJ-Y (5 min)
3	3.0000188	Arm pad
4	2.HLT15-25100300	Arm shaft
5	2.HLT15-26100300	cam
6	2.HLT15-38100300	Stop column
7	3.0000189	Safety limit switch
8	2.02HLT1518	Arm tube weldment
9	3.HLT1521000	PC transparent cover
10	2.02HLT1509030701	switch box
11	1.05.015311HLTY090	Button (white)
12	1.05.015211HLTY090	Button (red)
13	1.05.015111HLTY090	Button (green)
14	3.0000187	Bird mouth type knob
15	4.02.00000166	Water inlet
16	4.01.M10020GBT70_1036	M20 stainless steel nut
17	2.02HLT15060201	lid
18	2.HLT1513030200	Wave block
19	2.02HLT1513010202	Rotary casting (including bottom sand)
20	4.02.00000170--HLP20	Side sand wall
	4.02.00000171--HLP20	
21	2.02HLT150501	s/s pot
22	2.HLT15140201	Outlet door (including rubber)
23	2.02HLT15170701	Outlet handle
24	2.HLT15-31100300	BLOCKER
25	2.HLT150506	Leverage plate
26	2.02HLT150505	Switch trigger board
27	3.0000195	SEALING RING
28	2.HLT15080000	Spindle
29	4.01.6203GBT294166	Bearing

30	2.HLT-15-35120340	Isolation tube
31	3.0000194	SEALING RING
32	2.02HLT15120200	Big Belt wheel
33	1.03.00050003	Box of Electric board + CONTACTOR
34	4.01.03GBT117110600001	Multi-ribbed belt
35	1.04.15001411100	Motor (including small pulley)
36	2.02HLT152201010101	Seat for motor
37	2.02HLT15030201	Driver seat
38	2.000000038-1	Adjustable foot (including the foot pad)
39	2.02HLT15320601	Bracket strip
41	4.02.00000154	Water outlet
42	2.02HLT15330601	Leaking basin
43	2.HLT1410801	Stainless steel thin nut
44	2.02HLT1534010601	GN container
45	2.02HLT1501130701	Bottom plate
46	1.01.01.20044101	Power cord and plug
47	1.03.00040007	Cable gland
48	2.02HLT150108010701	Side panel
49	2.02HLT1501060601	BACK COVER
50	2.02HLT1501	Base
51	1.05.045011QKS15	breakout power switch when Open the door
52	3.0000179	Adjustable buckle
53	3.0000001	Buffer screw
54	2.02HLT15070201	Transmission seat
55	2.02HLT1502010801	Column
56	3.0000004	brush