

LPM-25A Spare Parts Price List

Part No.	English Name		Qty	
1	GN container lid		1	
2	Material rack		7	
3	Material seat		1	
4	Pot		1	
5	NTC temperature sensor		1	
6	Thermostat		2	
7	4" Inner thread elbow		1	
8	Insulation cotton		1	
9	Sealing strip		1	
10	Heating tube		1	
11	Ceramic fiber board		1	
12	Heating tube pressure plate		1	
13	Pressure plate spring		5	
14	Frame		1	
15	Power cord		1	
16	Power cord clip		1	
17	Handle		2	
18	Switch		1	
19	Spring pressure plate		1	
20	Relay		1	
21	Heat sink		1	
22	Circuit board		1	
27	Control panel		1	
23	Circuit board bracket		1	
24	Bottom plate		1	
25	S/S adjustable feet		4	
26	Membrane switch		1	
28	Panel rack		1	
29	4" straight joint		1	
30	4" oil valve		1	

