




Toaster				
S/N	Material Code	Description	Specification	Qty
01	302160071	Foot pad	Rubber, black	4
02	302090030	Rubber foot	Rubber, black	4
03	20210013022	Splash plate for crumb tray	SS	2
04	20210013017	Bottom plate	SS	1
05	20210013015	Crumb tray	SS	1
06	302090005	Ball handle	6*20 black, plastic	1
07	302080002	Spring		1
08	30200024	Pop-up part assembly	SS	1
09	20210012008	Chamber pressure plate	SS	1
10	20210013006	Front full plate		2
11	20210013004	Front chamber plate		1
12	301110145	Knob		1
13	302160017	Decoration plate	plactic, black	1
14	301080012	Switch	Red	1
15		Decoration plate ring	SS	2
16	301120016	Timer	5 min	1

17		Power cord		1
18	20110013001	Shell assembly	SS	1
19	20210013006	Rear full plate		1
20	20210013005	Rear chamber plate		1
21	302110199	Mesh		8
22		Heating element		5
23	20210013007	Heat insulationg plate		1
24	20210013014	Baffle for heating element		1
25		Fixed plate for wire	sheet mica	1
26	20210013009	Chamber pressure plate 2	SS	1
27	302210697	Screw	M4*10 round head	6