

No.	Part No.	Part Name	Q'ty
21	-	Custom latch assembly (Organic cover hook)	1
20	-	M6 nut sleeve / M8 insert	1
19	-	Overload protector	1
18	-	PMMA cover gasket	2
17	-	Pin	2
16	-	Aluminum base cotter pin	2
15	170x300N	Gas spring 170*300N	2
14	DZ400L004VX	Chamber cover	1
13	-	Aluminum connector block	2
12	DZ4002D0117V (Iron)	Wire screw (Iron)	4
11	DZ4002D0121V	Double-pass nut	4
9	DZ4002D0118V (S/S)	Wire screw (Stainless steel)	4
9	DZ4002D0120V	Wire screw washer	1
8	DZ4002D0218	Air bag connector	2
7	PJ001	Switch base	1
6	-	Knob / Rotary switch	1
-	DZ4002D0112V01	Sealing bar assembly	2
-	DZ4002D0112V02	Sealing bar assembly	1
-	DZ4002D0112V	Sealing bar	1
-	DZ4002D0116V	Stainless steel triangle	1
-	DZQ400B02V	Stainless steel bottom plate	1
-	DZ4002D0114V	Heater block fixing plate	4
-	-	Heating copper block	2
-	DZ4002D0113V	Heating wire	1
-	-	Heating copper block 2	2
-	DZ4002D0111V	Cutter holder	1
5	DZ4002D0115V	Heater block assembly	2
4	DZ4002D0119V	Seal ring	2
3	DZ4002D0115V	Air bag	2
2	DZ4002D0101V01 (New)	Vacuum chamber	1
1	DZ400T0001V01	Main cabinet	1
37	DZ400T0002V	Rear cover	1
36	-	Power socket	1
35	DZ4002D0302V	Pump foot spring	1
34	20 Feiyue	Feiyue vacuum pump	1
-	ISO 7047-M4x16-Z-16N	Screw ISO 7047-M4x16-Z-16N	1
33	M4x16	Screw M4x16	8
32	-	Solenoid valve 220V	1
31	-	Solenoid base	1
30	-	AC contactor 220V	1
29	-	Double sealed transformer 230V	1
28	DZQ400B01V08	Exhaust pipe	1
27	DZ400T003VX	Table base 400	1
26	M6x30	Screw M6x30	4
25	-	PCB (Single chamber)	1
24	-	Vacuum gauge	1
23	-	Control panel frame	1
22	-	Latch assembly 2	1

