

No	Part code	Part Description
1	1.1.0620.1133	Power board box fixer
2	1.2.0520.0647	Power board box
3	1.3.0420.0090	Power board
4	1.1.0620.0887	Power board box supporter
5	2.1.0200.0036	Foaming Cabinet Unit
6	1.1.0520.0223	Left Upper Hinge
7	1.1.0520.0220	Right Upper Hinge
8	1.1.0520.0608	Right Lower Hinge
9	1.1.0220.0210	Evaporator
10	1.3.0620.0001	Fan Motor
11	1.2.0220.0024	Fan Board
12	1.2.0520.0402	Carbon Filter
13	1.3.0320.0267	Temperature sensor
14	1.2.0520.0022	Temperature sensor Cover
15	1.3.0420.0098	Control PCB B
16	1.3.0520.0024	LED light
17	1.2.0620.0021	Single Zone Control Board Box
18	1.6.0720.0275	Display Panel
19	1.2.0520.0038	Shelf Lock
20	1.5.0120.0074	Big shelf
21	1.5.0120.0075	Small shelf
22	1.2.0320.0113	Door sealing
23	1.4.0320.0670	Left Glass Door
24	1.1.0720.0055	Door handle
25	1.1.0520.0005	Adjustable Lower Hinge
26	1.4.0320.0671	Right Glass Door
27	1.3.0420.0097	Control PCB A
28	1.1.0320.0047	Kickplate
29	1.1.0320.0065	Feet Supporter
30	1.2.0520.0003	Feet
31	1.1.0520.0049	L Shape Lock
32	1.1.0520.0612	Left Lower door hinge
33	1.1.0220.0025	Condensor
34	1.3.0620.0058	Condensor Fan motor
35	1.1.0620.0075	Fan Motor Cover
36	1.1.0620.0085	Fan Motor Support
37	1.3.0420.0436	Electric Magnet Valve
38	1.1.0320.0181	Compressor Plate
39	1.2.0520.0024	Water tray
40	1.3.0100.0063	Compressor
41	1.1.0220.0007	Air Out Tube
42	1.1.0220.0015	Artwork Tube
43	1.3.0220.0006	Power Cabel
44	1.1.0220.0065	Dryer Filter
45	1.1.0220.0019	Tee pipe
46	1.3.0320.0063	Earth Cable
47	1.3.0320.0074	Compressor Cable

