


Explosive drawing LP-818B



Part list:

1.Knob 2.Thermostat 3.Oil box 4.Body box 5.Heating element

6.Plate 7.Cable Plug 8.Feet 8.Bottom cover