



Part list:

- 1.Upper Electrical Box Cover
- 2.Power Line
- 3.Mounting plate
- 4.Connection plate
- 5.Heating element clamp
- 6.Upper plate
- 7.Heating element
- 8.Down Plate
- 9.Handle Support
- 10.Handle
- 11.Main coaming

- 12.Indicator Light
- 13.Water-proof switch
- 14.Knob cover
- 15.Knob seat
- 16.Thermostat
- 17.Timer knob
- 18.Timer
- 19.Bottom plate
- 20.Feet
- 21.Down electrical box cover
- 22.Connection terminal